


Amplifier section

Sensor section (Electrode)

There is no part of guard wire connection on the sensor side.



Leave the guard wire floating on the sensor side.

※ 1. For EMC (Electro Magnetic Compatibility) Details are in the instruction manual.

※ 2. Do not wire except for GUARD of the dedicated cable. If wired incorrectly, it will not operate properly.

※ You must ground this wire.

- ※ 3. Dedicated cable
- You can only use our dedicated cables.
- This product will not work properly if you do the following
 1. Cut the cable shorter in length.
 2. Wired the except for dedicated cables. Installed a connector in the middle of the cable.
 3. To easy connection and disconnection of the sensor.
- If the cable is long, do not cut it but wind the excess.

		TITLE				LT-EXD3 Type (CE marked product) Wiring Drawing		PROJECTION THIRD ANGLE		SCALE /		DWG No. A 1 7 0 2 - 8 4 8 6 3/3	
		REVISION		APPROVED		CHECKED		DRAWN		DATE			
M. K		DATE		REVISION						2017. 10. 18			